


Step 1: Reset Router

- Connect the router to the power supply and turn on the router.
- Press and hold the reset button on the back of the router for more than 10 seconds to reset the router to its factory default settings



Step 2: Connect Router


 Connect the WAN port to the LAN 1/UNID1 port of the Fiber Box (i.e., NBN box) via the Ethernet cable.

LAN port

Fiber box/ONT

Step 3: Setup Router

- There are two methods to connect with your router.
- Option 1 Ethernet cable connection:
 Connect the laptop/PC to any of the LAN ports (1 3 of the router) via Ethernet cable.





Step 3: Setup Router

- Option two Wi-Fi Connection: Connect your device (laptop, iPad, or spare phone) to the Wi-Fi.
- *How to check the Wi-Fi detail: Use SSID and Wireless password on **back of the router**.



SSID is the WIFI name, which may start with Occom. The PIN is the password.


Step 4: Login configuration page

1. Input **192.168.1.1** in the browser's address bar to visit the router's **configuration page**.

Username: Admin

Password: Occom_1234

2. Select **CWMP Settings** under **System Tools** on the left bar, disable/turn off the "**Inform DataModel with TR098**" function, and click **Save**.



- 3. In the **L2 Interface Type** choose **EWAN**.
- 4. Select the "Internet Connection Type" to PPPoE
- 5. Input the **PPPoE** username and password provided in the activation email, then click "Save".


L2 Interface Type:	O VDSL O ADSL ®	
VLAN:	☐ Enable VLAN ID	
Internet Connection Type:	PPPoE	٧
Username:		
Password:		Ø
Confirm Password:		Ø

	12 ALAKS 2 ALAS
Back	Next
Existing 1	INGAL
	10000000




Step 4: Login configuration page

- *Note: PPPoE username and password can be found in the activation email, if you cannot find yours, please do not hesitate to contact our friendly support team.
- 6. After a while, the third on the left light of your router is solid green which means you can access the Internet now.



Optional: Change your WiFi name and password/PIN

1. To change your Wi-Fi name and password, click Wireless -> Basic Settings. You can enter your WiFi name in Wireless Network Name on this page. Click the "Save" bottom after changing.





*Note: Because this is a dual-band router, it has 2 bands 2.4GHz and 5GHz. The settings in 2.4GHz and 5GHz are the same.

*Careful: Once you change your WiFi name or password, your device needs to reconnect with WiFi.

If the Internet still does not work, you can contact **OCCOM customer service** for assistance via

Email:

support@occom.com.au

Hotline: 1300 299 999