

TP-Link VR600 Setup Guide




Contents

1	Reset router	1
2	Setup router	1
	Ethernet cable connection	2
	WiFi connection.....	2
3	Login WIFI configuration page	3
4	Optional: Change your WiFi name and password/PIN.....	7

1 Reset router

- 1.1 Connect the router to power supply and turn on the router.
- 1.2 Press and hold this button for more than 10 seconds to reset the router to its factory default settings.



2 Setup router

- 2.1 Using an Ethernet cable to connect the WAN port.



2.2 There are two methods to connect with your router:

Ethernet cable connection

2.3 Turn off the WiFi on your laptop/PC and connect laptop/PC with any of LAN ports (1 –3 of router) via Ethernet cable.



WiFi connection

You can use your laptop, tablet or phone to connect with router for setting through WiFi.

2.4 You can find the WiFi name and password/PIN at the back of router.




- 2.5 Click the network icon of your computer or go to Wi-Fi Settings of your smart device, and then select the SSID to join the network.

***Careful:** Once your device connect with haven't configured router, your device will temporarily out of Internet. So please do not use the device which is currently using Internet.

3 Login WIFI configuration page

- 3.1 Open Internet browser (e.g. Google Chrome, Safari, etc.) and input <http://192.168.1.1/> or <http://192.168.0.1/> in the address bar to visit router's configuration page. Firstly, setup a password for the configuration page.



Please set up your Wireless Router Archer C1200 to connect to the Internet first. To begin, create a device password to manage your Wireless Router Archer C1200.

Password


Low Middle High

Confirm Password


Let's Get Started

*** Careful:** This is not the Password for your WiFi. This Password is only use for login configuration page, only the setup person know.


- 3.2 Click Advanced Button to view all setting.




3.3 Click Operation Mode



3.4 Choose Wireless Router Mode and Save. Then your router should restart for a while.



3.5 After restart and login the configuration page again, choose Advanced -> Network, then delete everything on the page.




3.6 After empty the page, Add a new one



3.7 Change Internet Connection Type to PPPoE

Ethernet Configuration

VLAN ID: ☐ Enable

Internet Connection Type: 

Username:

Password:

Confirm Password:

Connection Mode: ☒ Auto ☐ On Demand ☐ Manually

Authentication Type:

IPv4: ☒ Enable

Default Gateway:

IPv6: ☐ Enable

☐ Advanced

MAC Clone

☒ Do NOT Clone MAC Address

☐ Clone Current Computer MAC Address

☐ Use Custom MAC Address

Connection Type: ✓ Dynamic IP
Static IP
PPPoE
L2TP
PPTP

Enable IPv4: ☒

IP Address:

Subnet Mask: 0.0.0.0

Gateway: 0.0.0.0

Enable MER ☐

Renew **Release**

Enable IPv6: ☐

- 3.8 Input the PPPoE username and password provided by us, then click “Save”. You can find these username and password in the Service Activation Notice Email. (Ensure the Connection Mode is Always on and please save other as default.) Save the change.

Ethernet Configuration

VLAN ID: ☐ Enable

Internet Connection Type: PPPoE

Username:

Password:

Confirm Password:

Connection Mode: ☒ Auto ☐ On Demand ☐ Manually

Authentication Type: Auto

IPv4: ☒ Enable

Default Gateway: Current Connection

IPv6: ☐ Enable

Advanced

MAC Clone

☒ Do NOT Clone MAC Address

☐ Clone Current Computer MAC Address

☐ Use Custom MAC Address


- 3.9 After a while, the third one on the button light of your router is solid green which means you can access the Internet now.



4 Optional: Change your WiFi name and password/PIN

4.1 Change WiFi name & Password:

Click Wireless -> Wireless Settings. You can enter your WiFi name in Network Name and Password in this page. Click "Save" bottom after changing.



***Careful:** Once you change your WiFi name or password, your device needs to reconnect with WiFi.